

PHILIPS VIDEOPAC 30



Battlefield
Schlachtfeld
Champ de bataille
Slagveld
I due generali
Guerillakrig
Fånga Generalen
Campo de batalla
A batalha

PHILIPS



Instructions for Use

ENG

Battlefield

First read these instructions before you start to play

(2 players) Press RESET

Next press key 1

Your screen shows a small forest and two armies, each with a general. In the left-hand top corner you'll see the blue general and his four soldiers (left handset), in the right-hand bottom corner a yellow general with his four soldiers (right handset).

The purpose of the game is to capture the enemy general. If you succeed in capturing him ten times, you have won the war.

How the game is played

You cannot control your soldiers directly. They will automatically try and find their way to the other general. When they encounter enemy soldiers, they may shoot them.... or get shot by an enemy bullet. When hit by a bullet, they are stunned and will not move any more. The generals are invulnerable to enemy bullets.

You can move your general however with the joystick of your handset. This way you may try and escape from pursuing enemy soldiers. Your general can also re-animate your soldiers that have been shot. When he touches them, they will revive.

As a true general he may also lead his men to the enemy camp. Use the joystick to control his movements. When you press the action button, he will beckon his soldiers to follow him. They will, provided their way isn't blocked by trees or soldiers. Once they have a clear path to the opposing general, you can let them go and they will pursue him automatically.

When one of the generals is captured, both officers first act in a very gentlemanly fashion but not for long. There's not much time to

rejoice because the game continues immediately and winning a battle doesn't mean you have won the war! It takes ten victories to win one war with this Videopac game.

Starting a new series

Immediately after one war has been fought and the winner is known, a next one will start so you continue to play.

Check procedure

If you suspect a fault in the equipment follow this procedure (with a Videopac installed): Press RESET (Δ). The TV will emit a short sound, and 'SELECT GAME' should appear on your TV screen. If not, ensure that the equipment is set up properly as detailed in the Instructions for Use (both of the

equipment, and of the Videopac used). If the fault remains, take both the equipment and Videopac to your dealer.


Score blue army
(left handset)

Trees

No score for blue army

Blue
general


Blue
soldiers



Yellow
soldiers
Score
yellow
army
(right
handset)

Blue
general
salutes
his
opponent

Yellow
army
has
scored
one
point



Start of the game

Both generals and their four-man armies are still in their own corners. Soldiers will automatically start searching for the opposing general.

Yellow soldier has
captured the blue general

Yellow general
salutes his opponent

Game situation

Yellow army scores its first victory



Press action button and general beckons
his soldiers to follow him


Use joystick to move your general

Soldiers stunned by enemy buffet. They
will come to life again when touched by
their general

Blue
army has
scored
one point

Blue
general
jumps
with joy

Blue
soldier
has
captured
yellow
general




Yellow general shows anger about losing

Game situation

Blue army scores its first victory

Score blue army

Blue general
the victor, grows
in stature when
he celebrates
his victory



Blue soldier has captured
yellow general

Game situation

War is over. The blue army has scored ten
victories

Score
yellow
army

Each time a game is finished,
press RESET (.), 'SELECT GAME'
is shown on the screen. Now

Refer now to instructions for
Use of the next Videopac.

Or (c) Plug aerial back into TV, and
unplug the Videopac
Computer from the mains

(a) Select another game
Or (b) Select another Videopac
Remove existing Videopac
by placing one hand next to
it, and pulling handle
upwards.
Replace Videopac in its box.

A copyright protection is claimed
on the program stored within the cartridge.

© 1981 N.V. Philips' Gloeilampenfabrieken

3111 106 62790

SIP